# Important safeguards

xBloom takes care of brewing beans to perfection so you can tap into a world of new taste. But please brew with caution, and read these instructions before use.

- Do not insert water or any other object into the bean port. Inserting anything other than roasted coffee beans into the grinder voids the guarantee.
- To prevent scalding, do not put your hand under the water outlet when machine is in
- To prevent scratch damage when cleaning the machine, refrain from using iron wires, steel brushes, or similar utensils. It is advised to use a damp soft cloth instead.
- · Do not put heavy objects on the xPod holder.
- Never leave the machine unattended when in use.
- Close supervision is necessary when any appliance is used by or near children. Do not use or leave unattended within reach of children.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety. Children should be supervised at all times.
- In case of emergency, immediately remove the plug from the power socket.
- Only plug the appliance into suitable, easily accessible, earthed mains connections. Ensure the voltage power source aligns with what's specified on the rating plate. The use of an incorrect connection voids the guarantee.
- In case of plug incompatibility with the socket, use an adaptor to ensure the ground continuity between the machine and the network.
- · A short power supply cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord. If an extension cord is used, the marked electrical rating of the extension cord must be at least as great as the rating of the coffee brewer. The extension cord must be a grounding type 3 cord. The extension cord should be arranged so it doesn't drape over the counter or table top where it can be pulled over by children or tripped over.
- Do not use the machine in strong, direct sunlight, which will affect the water level detection of the water reservoir.
- At sea level, the boiling temperature is 100°C/212°F. At higher elevations, the boiling temperature can be as low as 90°C/194°F, resulting in excessive steam coming out of the steam outlet. Please be aware when using xBloom at higher altitude.

A CAUTION: To prevent burns, do not touch the steam outlet or bring your hands or face near the steam outlet.

### The appliance must only be connected after installation.

- . Do not pull the cord over sharp edges. Secure it or allow the cord to hang freely in an unobstructed area
- . Keep the cord away from heat and dampness.
- If the supply cord or the plug are damaged, they must be replaced by the
- manufacturer, its service agent, or similarly qualified persons to avoid all risks. • Do not operate any appliance with a damaged cord or plug or after the appliance
- malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair, or adjustment.
- To avoid hazardous damage, never place the appliance on or beside hot surfaces such as open flames, radiators, stoves, ovens, gas burners, or similar devices.
- Always place the machine on a horizontal, stable, and even surface. The surface must be resistant to heat and fluids, such as water, coffee, descaling products, or similar
- . Disconnect the appliance from the mains when not in use for long periods. Disconnect by pulling the plug and not by pulling the cord itself or the cord may
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting
- on or taking off parts, and before cleaning the appliance. · Never touch the cord or plug with wet hands.
- . To protect against fire, electric shock, and injury to persons, do not immerse the cord
- or plug in water. · Never immerse the appliance in any liquid
- Never put the appliance or any part of it in a dishwasher, except the disassembled xPod Dock and Magnetic Tunnel. It is recommended not to use a dishwasher to avoid
- Electricity and water interaction is dangerous and can lead to fatal electrical shocks.
- Do not open the appliance. Hazardous voltage inside.
- Do not put any objects or tools into any openings. Doing so may cause fire or

# Welcome to xBloom

Experience the authentic taste of specialty coffee at home.

Scan the OR code to get started

or visit: www.xbloom.com/pages/app

www.xbloom.com/pages/app

# Before you use xBloom


To ensure everything runs smoothly, please read all use and safety instructions fully before using your machine.


### VIDEO: SET UP

www.xbloom.com/setup

## Set up xBloom

Meet your new machine! Setting up xBloom is easy, just follow the steps below.





Step 1

specialty coffee awaits.

Place the xPod on the sensor pad (RFID)

Fresh specialty coffee made simple

In just three simple steps, you'll be enjoying your first cup. A new world of

VIDEO: MAKING COFFEE

www.xbloom.com/makingcoffee

to activate bean recognition.



Pour the beans into the grinder and place the empty pod in the dock.



# Step 3

Press the dock gently downwards and let he machine take care of the rest.

# About the app

Once you've set up your xBloom, the app will act as your personal coffee companion. Learn more about your beans and the incredible craftsmen behind them.

Take control and brew on your terms to discover new flavors. Delve into a marketplace of curated quality coffee. All from the palm of your hand.

### Get creative mode

Play and experiment with grind size, water temperature, time, and pouring pattern, with the comfort of always being able to return to the recipes set by our barista partners. Our app also allows you to use the grinder standalone.

### **VIDEO: GET CREATIVE MODE**

www.xbloom.com/getcreative

# About the xPod

Each xPod contains a unique recipe set by the baristas and roasters behind the beans. xBloom reads the label and brews accordingly to extract the best flavor.

### The xPod capsule


The xPod is more than a capsule. It contains a built-in filter as well as 15~16ø of freshly roasted beans, ready for you to grind and brew with xBloom

### The filter design

Our filter design was shaped to deliver a balanced cup of coffee every time you use xBloom. Its flat bottom and holes allow for even distribution of water and coffee grinds, an important element in our precision brewing process.

# The xPod recipe label (RFID)

The recipe label, on the bottom of the xPod, is the key to the xBloom machine. The machine reads the coffee bean type and recipe information stored in the label, and adjusts the grind size, water temperature, brew ratio, time and pattern based on the recipe.



When an indicator light is blinking, xBloom is taking care of that step in the brewing process. When the fourth indicator light turns solid, brewing is completed.







www.xbloom.com

THIS PRODUCT IS FOR USA AND CANADA: HOUSEHOLD USE ONLY

polymer matrix and are not expected to be hazardous to health.

• The use of accessory attachments not recommended by the appliance manufacturer may

. Do not use the appliance if it is damaged, has been dropped, or is not operating correctly.

Immediately remove the plup from the power socket. Contact xBloom or an authorized

Always fill the water reservoir with cold drinking water. Do not pour hot water or other

Replace water in the water reservoir when the appliance is not operated for a weekend or

• Do not use any strong cleaning agent or solvent cleaner. It is advised to use a damp cloth

This appliance is designed for xBloom coffee capsules or specific xBloom accessories

are performed on randomly selected units. This can show traces of any previous use.

All xBloom appliances pass stringent controls. Reliability tests under practical conditions.

Operating or storing environment temperature shall be between 5°C/41°F - 38°C/100°F.

Descale according to user manual recommendations or consult the descaling information

△ CAUTION: Continuous brewing in a short period may cause the temperature of the xPod holder

to reach up to 50 °C/122°F. It is advisable to allow a 5-minute cool-down period before handling.

△ CAUTION: The descaling solution can be harmful. Avoid contact with eyes, skin, and

surfaces. The use of any unsuitable descaling agent may lead to machine component

damage or an insufficient descaling process. For any additional questions regarding

• To maintain continued safety please pass instructions on to any subsequent user.

**△WARNING**: This product can expose you to chemicals including 4-Vinyl Cyclohexene,

Acetaldehyde, Acrylonitrile, Alpha-Methyl-Styrene, Butadiene, Carbon Black, Cumene,

cause cancer, and Butadiene, which is known to the State of California to cause birth

Note: According to the resin manufacturer, these ingredients are present within the

Ethylbenzene, Styrene and Titanium Dioxide, which are known to the State of California to

defects or other reproductive harm. For more information go to www.p65warnings.ca.gov.

This instruction manual is also available as a PDF at www.xbloom.com.

available exclusively through xBloom or your authorized xBloom representative.

\* xBloom reserves the right to change instructions without prior notice.

Use the drainage function to drain remaining water before moving the machine.

Empty the water reservoir if the appliance is not to be used for an extended time

result in fire, electric shock, or injury to persons.

Avoid possible harm when operating the appliance.

Remove the xPod dock before moving the machine.

beverages into the water reservoir.

. To clean the machine, use only clean tools.

(holidays, etc.).

a similar period.

Do not put fingers under coffee outlets. Risk of scalding.

and mild cleaning agent to clean the surface of the appliance.

Do not use the appliance for other than intended use.

by visiting the xBloom website: www.xbloom.com.

descaling, please contact xBloom directly.

SAVE THESE INSTRUCTIONS

xBloom representative for examination, repair, or adjustment.

A damaged appliance can cause electrical shocks, burns, and fire.


Do not put fingers into the grinder component. Danger of injury.

Do not use outdoors.




# xBloom machine overview

Get to know your home barista, the xBloom machine. Dig into the details, this will ensure everything works as expected and help to protect your warranty.



ength, width, height	20cm, 17.5cm, 43cm (7.87 in, 6.89 in, 16.93in)
Net weight	5.2kg (11.46 lbs)
Cord length	1m (3.3 ft)
Voltage, frequency	120V, 60Hz
Power	1350 W
Nater temperature at heater	up to 99°C (210°F)
Nater temperature at dispenser	up to 95°C (203° F)
Water reservoir	700ml (23.67 fl. oz)
Grind range	30 settings for pour over
Grind size	18.75µm per step



# The Button

From bluetooth pairing to pausing the brewing process, the Button on the back of your xBloom machine will enable you to carry out a multiple actions:

One short press will pause the grinding or water pouring process. Press the Button again when you're ready to resume grinding or pouring water.

Three short presses within two seconds will stop xBloom, which will return to standby mode, ready to start brewing.

Five short presses within two seconds will activate/deactivate Bluetooth and Wi-Fi. The status indicator will flash fast when Wi-Fi and Bluetooth are switched off.

Pressing for three seconds will put the xBloom in Bluetooth pairing mode. Search for xBloom on your device, connect, and get brewing with the app. The status indicator will flash slowly before the Wi-Fi and Bluetooth are connected, and will remain solid once connected.

Pressing for ten seconds or longer will drain the water from the machine as long as you keep the Button pressed.

# **Troubleshooting**

STATUS

No light on the

First display bar

Second light

blinking

blinking

blinking together

Status indicator

www.xbloom.com/fags

blinking

display panel

We're sorry something isn't working as you expected, but a simple solution should get you back on track. Check out common quick fixes below.

**PROBLEM** 

 The machine is not plugged in.

 The machine is in standby mode.

• No coffee beans in

the grinder.

auto-restart.

• The grinder is

stuck and waiting to

· Water isn't flowing

freely from the water

· Operation with the

Waterway failure.

· Water level below

The xPod scanned

has already been used.

minimum value.

technical support

· The machine is not

connected to the

Internet.

For more questions please refer to the FAQ section on our website:

wrong type of voltage.

reservoir

detected

All the display bars Problem that needs

SOLUTION

and fuse.

· Check the plug, voltage,

· If there are no beans, the

standby mode, add beans and

· If stuck, the grinder will wait for 3 seconds and try grinding

· If the problem persists after restarting, or there is a

foreign object in the grinder,

contact customer support.

Check the water inlet for

· Descale the machine.

 Ensure that your main supply voltage is the same as

that in the specifications.

· If the problem persists after restarting, contact customer

 Check if the water reservoir is installed, if not, install it.

· Each xPod can be used only

Add water above the

once. Do not reuse xPod.

· Check if the Wi-Fi or

· Re-connect the machine to

• Press the button 5 times to

turn on the Wi-Fi function.

hotspot is working as

expected.

the internet.

Contact xBloom

customer support.

minimum value line.

foreign objects.

machine will return to

operate again.

# Taking care of xBloom

xBloom was built with a lot of love so show it some care. Should you have any issues with your machine, please check our warranty below.





### VIDEO: AFTER USE

www.xbloom.com/afteruse

### Cleaning and Storing xBloom

- Use a clean damp cotton cloth to wipe off the dirt on the coffee machine.
- . We recommend removing the magnetic tunnel and cleaning the grinder residue once a week with the provided cleaning brush, based on daily use.
- . Clean and dry all parts before storing the machine in a safe place.
- To drain any remaining water, press the button for 10 seconds until water starts to flow from the pouring mouth, making sure to have a recipient on hand to catch the water. Release your finger from the button to stop water flowing.

Descaling xBloom
• To keep the xBloom looking and performing its best, we recommend a regular routine of cleaning the machine. xBloom recommends descaling your brewer every 500 cycles. Use only dedicated descaling products for home coffee machines. Commercial cleaning products, or those not designed for coffee machines, could damage your xBloom and might invalidate the warranty. We also do not recommend using vinegar to descale your machine, as it is often not strong enough of an acid to remove mineral buildup, and it can leave behind residue that will affect the aroma of your coffee.

- 1. Fill the water reservoir with a dedicated descaling product diluted with water according to the directions on the package.
- 2. Press and hold the Button to drain the machine and wait until all the liquid has flowed into a recipient before releasing.
- 3. Rinse all components. Repeat the drainage cycle three times with clean water.

# Service or repair

· For service, repair, or any questions regarding your appliance, first visit www.xbloom.com/faqs. If you still have questions, reach out to us at support@xbloom.com. Do not mail the product back to the manufacturer or bring it to a service center without

first talking to a xBloom customer support representative.

# One-year limited product warranty


We offer one-year limited warranty (upon delivery) on machines purchased directly

Our limited warranty covers defects in materials and workmanship in every xBloom product you purchase during the applicable warranty period, subject to certain exceptions. The warranty period is not extended if we repair or replace a warranted product. xBloom may change the availability of limited warranties, at our discretion, but any changes we make will not be applied retroactively.

Please note that we do not provide warranty coverage for:

- Problems that result from external causes such as accident, abuse or misuse.
- · Usage that is not in accordance with xBloom product instructions.
- · Products that are used outside of North America (i.e. U.S. and Canada).
- · Products with missing or altered serial numbers.
- · Products that have had their housings opened or have otherwise been tampered with.
- · Problems caused by using third party accessories, parts, or components.
- · Problems caused by using non xBloom pods.

If you experience any issue with your machine, please reach out to us at support@xbloom.com



User manual

Model FW-01A